




MPI-540 / 540-PV





Much more than a multifunctional meter

- The largest touch screen on the market (7") remarkable ergonomics and ease of use
- Removable microSD memory card easy increase of memory capacity
- Li-lon battery longer operation of the meter
- MPI-540-PV | Measurement of photovoltaic installations according to EN 62446 standard
- MPI-540-PV | Photovoltaic installation test report with Sonel Reports PLUS software
- Three-phase power recorder advanced power quality diagnostics
- Real time display of network parameters immediate evaluation of the test site conditions
- Parameters measured in accordance to class S of EN 61000-4-30 standard high accuracy of measurements
- Energy cost calculator quick evaluation of potential savings
- Measurement of all parameters related to earthing and protection against electric shock one device instead of several
- Quick measurement of the fault loop impedance in networks secured with RCD without triggering (up to several seconds) – time saver
- Auto measurements the ability to perform automatic measurements in sequence simplified measurements
- Fast path from measurements to report time saver

Choose the best set for your needs

F-3A flexible coils



MPI-540-PV Solar includes flexible coils and solar radiation measurement set













MPI-540 includes flexible coils





MPI-540 Start does not include flexible coils







Features

The meter has **above-average functionality**. It combines the measuring capabilities of several devices, while ensuring equally good accuracy.

- The **MPI-540-PV** instrument can measure photovoltaic installations in accordance with the EN 62446 standard:
 - » continuity of protective and equipotential bondings,
 - » earth resistance,
 - » insulation resistance on the DC side,
 - » open circuit voltage U_{oc},
 - » short circuit current I_{sc},
 - » work currents and powers on both DC and AC side,
 - » inverter efficiency.
- MPI-540 / MPI-540-PV can record 50/60 Hz power quality parameters in accordance to S class of EN 61000-4-30:
 - » voltage L1, L2, L3, average values in the range up to 500 V,
 - » L1, L2, L3 currents, average values, current measurement in the range up to 3 kA (depending on the current probes used),
 - » frequency in the range of 40 Hz 70 Hz,
 » active (P), reactive (Q) and apparent (S) power,
 - » power factor (PF), $\cos \varphi$,
 - » harmonics (up to 40th for voltage and current),
 - » total harmonic distortion (THD) for current and voltage.
- MPI-540 / MPI-540-PV can be used for all measurements for commissioning of electrical installations in accordance with applicable regulations:
 - » short circuit loop impedance (also in circuits secured with RCDs),
 - » RCD parameters,
 - » insulation resistance,
 - » earth resistance (4 measurement methods + soil resistivity measurement),
 - » continuity of protective and equipotential bondings,
 - » light intensity measurement,
 - » phase sequence test,
 - » motor rotation direction test.



Automatic installation safety test

MPI-540 / MPI-540-PV allow safety control of **residential, commercial and industrial electrical installations**. Measurements can be easily automated with:

- auto mode of residual current devices (RCD) tests,
- auto measurements freely configurable measuring sequences,
- AutoISO-1000C adapter for automatic insulation resistance test of 3-, 4and 5-conductor cables, without switching.

Photovoltaics under supervision

MPI-540-PV is an extremely universal meter, designed in particular for testing photovoltaic installations. The device allows a complete set of tests on the DC and AC side – in accordance with the guidelines of EN 62446 standard.

Measuring parameters related to the photovoltaic installation, the instrument will automatically convert them to the STC (Standard Test Conditions) reference conditions. Measurements of voltage, current and power on the AC and DC side of the inverter allow to verify its efficiency. **Sonel Reports PLUS** software enables creating PV installation test report with measurement results saved meter's in memory.




Three-phase power quality recorder

The device has a three-phase power quality recorder with the LIVE mode view and the possibility to register electrical network parameters such as voltage, current, power, harmonics and THD. The meter enables reading of selected parameters and their graphic presentation on the screen in real time. These parameters are measured and displayed concurrently with the recording on the memory card. In the LIVE mode, the user can see:

- voltage and current waveforms (oscilloscope),
- voltage and current timeplots,
- a phasor graph,
- display of multiple parameters in tabular form,
- spectrum graph of current and voltage harmonics.

Ease of reading

The device is equipped with a color TFT LCD touch screen with a resolution of 800x480 pixels and a diagonal of 7", which allows for convenient operation and easy reading of parameters and plotted waveforms. This screen size enables displaying more information, available at any time of use. The interface is visible in all conditions – also thanks to the appropriate size of displayed symbols. **Included stylus allows to work also with dielectric gloves.**



Built-in help system

The device has built-in help screens with measurement diagrams. Thanks to this you can easily and quickly check and make sure how to connect to a given system depending on the type of performed measurement.





Increased resistance to environmental conditions

The MPI-540 / MPI-540-PV meter will cope well in difficult environmental conditions. Protection against penetration of dust and water is ensured by a unique housing with a level of protection IP51. It is resistant to mechanical damage, and a special design allows you to easily protect the touch screen by shielding using the cover of the meter. In addition to the fact that it protects against damage, it also allows you to conveniently carry and use the device in different positions.

Communication and software

A very strong feature of the device is the multitude of communication interfaces and cooperation with external software. You can easily transfer measurement data to your computer via USB port, removable SD memory card, or wireless communication (Bluetooth, Wi-Fi).

In order to generate a report on measurements for electric shock protection, use **Sonel Reports PLUS** software. Saving the downloaded data to the simplest formats and printing is provided by free **Sonel Reader** software. The specialized, free **Sonel Analysis** software is used to read and analyze data from the power quality recorder.

| Measurement functions | Measurement range | Display range | Resolution | Accuracy ±(% m.v. + digits) |
|--|--|------------------|---------------|--|
| ault loop impedance | | | | |
| Fault loop $Z_{L-PE'}^{} Z_{L-N'}^{} Z_{L-L}^{}$ | 0.13 Ω 1999.9 Ω acc. to IEC 61557 | 0.000 Ω1999.9 Ω | from 0.001 Ω | ±(5% m.v. + 30 digits) |
| Fault loop Z_{L-PE} in RCD mode | from 0.50 Ω1999 Ω acc. to IEC 61557 | 0.00 Ω1999 Ω | from 0.01 Ω | from ±(6% m.v. + 5 digits) |
| Measurements of RCD parameters | | | | |
| RCD tripping test and measurement of tripping measuring current 0.5 I_{_{\Delta n'}} 1 I_{_{\Delta n'}} 2 I_{_{\Delta n'}} 5 I_{_{\Delta n}} | ng time t _A | | | |
| general and short-time delay RCD | 0 ms300 ms | 0 ms300 ms | 1 ms | from ±(2% m.v. + 2 digits) |
| selective RCD | 0 ms500 ms | 0 ms500 ms | 1 ms | from ±(2% m.v. + 2 digits) |
| Measurement of RCD tripping current I_A measuring current 0.2 $I_{\Delta n}$ 2.0 $I_{\Delta n}$ | | | | |
| for sinusoidal residual current (AC type) | 3.3 mA1000 mA | 3.3 mA1000 mA | from 0.1 mA | $\pm 5\% I_{\Delta n}$ |
| for unidirectional residual current and unidirectional with the 6 mA DC bias (type A) | 3.5 mA700 mA | 3.5 mA700 mA | from 0.1 mA | $\pm 10\%$ I _{Δn} |
| for direct residual current (type B) | 2.0 mA1000 mA | 2.0 mA1000 mA | from 0.1 mA | $\pm 10\%$ I _{Δn} |
| Carth resistance | | | | |
| 3- and 4-pole method | from 0.50 Ω1.99 kΩ acc. to IEC 61557-5 | 0.00 Ω1.99 kΩ | from 0.01 Ω | from ±(2% m.v. + 3 digits) |
| 3-pole + clamp method | 0.00 Ω1.99 kΩ | 0.00 Ω1.99 kΩ | from 0.01 Ω | from ±(2% m.v. + 4 digits) |
| 2-clamp method | 0.00 Ω99.9 kΩ | 0.00 Ω99.9 kΩ | from 0.01 Ω | from ±(10% m.v. + 4 digits |
| Resistance-to-earth | 0.0 Ωm99.9 kΩm | 0.0 Ωm99.9 kΩm | from 0.1 Ωm | Depending on accuracy of R _e measurement |
| nsulation resistance | | | | |
| Measuring voltage 50 V | 50 kΩ250 MΩ acc. to IEC 61557-2 | 0 kΩ250 MΩ | from 1 kΩ | from ±(3% m.v. + 8 digits) |
| Measuring voltage 100 V | 100 kΩ500 MΩ acc. to IEC 61557-2 | 0 kΩ500 MΩ | from 1 kΩ | from ±(3% m.v. + 8 digits) |
| Measuring voltage 250 V | 250 kΩ999 MΩ acc. to IEC 61557-2 | 0 kΩ999 MΩ | from 1 kΩ | from ±(3% m.v. + 8 digits) |
| Measuring voltage 500 V | 500 kΩ2.00 GΩ acc. to IEC 61557-2 | 0 kΩ2.00 GΩ | from 1 kΩ | from ±(3% m.v. + 8 digits) |
| Measuring voltage 1000 V | 1000 kΩ9.99 GΩ acc. to IEC 61557-2 | 0 kΩ9.99 GΩ | from 1 kΩ | from ±(3% m.v. + 8 digits) |
| Resistance of protective conductors and equi | potential bondings | | | |
| Measurement of resistance of protective conductors and equipotential bondings with ±200 mA current | 0.12 Ω400 Ω acc. to IEC 61557-4 | 0.00 Ω400 Ω | from 0.01 Ω | ±(2% m.v. + 3 digits) |
| Measurement of resistance with low current | 0.0 Ω1999 Ω | 0.0 Ω1999 Ω | from 0.1 Ω | ±(3% m.v. + 3 digits) |
| ight intensity | | | | |
| Measurement in luxes (lx) | 0 lx399.9 klx | 0 lx399.9 klx | from 0.001 lx | from ±(2% m.v. + 5 digits) |
| Measurement in feet-candles (fc) | 0 fc39.99 kfc | 0 fc39.99 kfc | from 0.001 fc | from ±(2% m.v. + 5 digits) |

Specifications – 3-phase power quality recorder

The device is designed to work with mains:

- » with nominal frequency 50/60 Hz
- with nominal voltage: 64/110 V, 110/190 V, 115/200 V, 127/220 V, 220/400 V, 200/400 V, 200/400V, 200/400V, 200/400V, 200/400V, 200/400V, 200/400V, 200/400V, 200/40
- 220/380 V, 230/400 V, 240/415 V, 254/440 V, 290/500 V
- » DC networks

Supported systems:

- » single-phase
- » split-phase with common N
- » three-phase WYE with and without N conductor
- » three-phase Delta

| Parameter | Measuring range | Max. resolution | Accuracy | |
|---|---|--|--|--|
| Alternating voltage (TRMS) | 0.0500 V | 0.01% U _{nom} | ±0.5% U _{nom} | |
| Alternating current (TRMS) | depending on clamp* | 0.01% I _{nom} | $\pm 2\%$ m.v. if m.v. ≥ 10% I _{nom} $\pm 2\%$ I _{nom} if m.v. < 10% I _{nom} (error does not account for clamp error) | |
| Frequency | 40.0070.00 Hz | 0.01 Hz | ±0.05 Hz | |
| Active, reactive, apparent and distortion power | depending on configuration (transducers, clamps) | 4 significant digits | depending on configuration (transducers, clamps) | |
| Active, reactive and apparent energy | depending on configuration (transducers, clamps) | 4 significant digits | as power error | |
| cosφ and power factor (PF) | 0.001.00 | 0.01 | ±0.03 | |
| Harmonics | | | | |
| Voltage | as for alternating voltage True RMS | as for alternating voltage True RMS | ±5% m.v. if m.v. ≥ 3% U _{nom} ±0.15% U _{nom} if m.v. < 3% U _{nom} | |
| Current | as for alternating current True RMS | as for alternating current True RMS | ±5% m.v. if m.v. ≥ 10% I _{nom} ±0.5% I _{nom} if m.v. < 10% I _{nom} | |
| THD | | | | |
| Voltage | 0.0100.0% | | - | |
| Current | (relative to RMS value) | 0.1% | ±5% | |
| Unbalance factor | 0.010.0% | 0.1% | ±0.15% (absolute error) | |

* F-1A, F-2A, F-3A clamp: 0...3000 A AC (10 000 A_{pp}) • C-4A clamp: 0...1000 A AC (3600 A_{pp}) • C-5A clamp: 0...1000 A AC/DC (3600 A_{pp}) • C-6A clamp: 0...10 A AC (36 A_{pp}) • C-7A clamp: 0...100 A AC (360 A_{pp})

| | | | | × | Ö | \bigcirc | Q |
|--|-------------|------------------------|-------------|-------------|-------------|-------------|-------------|
| | C-4A | C-5A | C-6A | C-7A | F-1A | F-2A | F-3A |
| | WACEGC4A0KR | WACEGC5AOKR | WACEGC6AOKR | WACEGC7A0KR | WACEGF1AOKR | WACEGF2A0KR | WACEGF3A0KR |
| Rated current | 1000 A AC | 1000 A AC 1400 A DC | 10 A AC | 100 A AC | | 3000 A AC | |
| Frequency | 30 Hz10 kHz | DC5 kHz | 40 Hz10 kHz | 40 Hz1 kHz | | 40 Hz10 kHz | |
| Max. diameter of measured conductor | 52 mm | 39 mm | 20 mm | 24 mm | 380 mm | 250 mm | 140 mm |
| Minimum accuracy | ≤0.5% | ≤1.5% | ≤1% | 0.5% | | 1% | |
| Battery power | _ | \checkmark | _ | _ | | _ | |
| Lead length | 2.2 m | 2.2 m | 2.2 m | 3 m | | 2.5 m | |
| Measurement category | IV 300 V | IV 300 V | IV 300 V | III 300 V | | IV 600 V | |
| Ingress protection | | IF | P40 | | | IP67 | |

MPI-540-PV | Specifications – photovoltaic installation parameters

| Measurement functions | Display range | Resolution | Accuracy ±(% m.v. + digits) |
|---------------------------------------|------------------|------------|--------------------------------|
| Open circuit voltage U _{oc} | 0.0 V1000 V | from 0.1 V | from ±(3% m.v. + 2 digits) |
| Short circuit current I _{sc} | 0.00 A20.00 A | 0.1 A | ±(3% m.v. + 0.10 A) |

Other technical data

Safety and work conditions

| Measuring category according to EN 61010 | IV 300 V, III 500 V MPI-540-PV II 1000 V DC |
|---|--|
| Ingress protection | IP51 |
| Type of insulation according to EN 61010-1 and IEC 61557 | double |
| Dimensions | 288 x 223 x 75 mm |
| Weight | ca. 2.5 kg |
| Operating temperature | 0+45°C |
| Storage temperature | -20+60°C |
| Humidity | 2090% |
| Nominal temperature | 23 ± 2°C |
| Reference humidity | 40%60% |
| Memory and communication | |
| Memory of measurement results | unlimited |
| Data transmission | USB 2.0 |
| Other information | |
| Quality standard – development, design and production | ISO 9001 |
| The product meets the EMC (emission for industrial environment) requirements according to standards | EN 61326-1 EN 61326-2-2 |



Standard accessories

| | | MPI-540-PV Solar | MPI-540-PV | MPI-540-PV Start | MPI-540 | MPI-540 Start |
|---------------------------------------|--|---------------------|--------------|---------------------|------------|------------------|
| | | WMGBMPI540PVIRM1 | WMGBMPI540PV | WMGBMPI540PVNC | WMGBMPI540 | WMGBMPI540NC |
| | Solar radiation measurement set (IRM-1 solar radiation and temperature meter + IRM-1 mounting&measuring set + Z24 power supply + USB adapter for LoRa data transmission + M14 carying case) WMGBIRM1MPI | 1 | | | | |
| ~ | PVM-1 adapter WAADAPVM1 | 1 | 1 | 1 | | |
| H. | MC4-banana sockets adapter (set) | 1 | 1 | 1 | | |
| Ċ- | WS-03 adapter with START button with UNI-Schuko plug (CAT III 300 V) WAADAWS03 | 1 | 1 | 1 | 1 | 1 |
| | C-PV clamp WACEGCPVOKR | 1 | 1 | 1 | | |
| and the | Adapter for C-PV clamp | 1 | 1 | 1 | | |
| Ò | F-3A flexible clamp (Ø 120 mm) WACEGF3AOKR | 3 | 3 | | 3 | |
| 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 | Test lead 1.2 m (banana plugs) black / red / blue / yellow WAPRZ1X2BLBBN / WAPRZ1X2REBB / WAPRZ1X2BUBB / WAPRZ1X2YEBB | 1/1/1/1 | 1/1/1/1 | 1/1/1/1 | 1/1/1/1 | 1/1/1/1 |
| 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 | Crocodile clip 1 kV 20 A black / red / blue / yellow WAKROBL20K01 / WAKRORE20K02 / WAKROBU20K02 / WAKROYE20K02 | 1/1/1/1 | 1/1/1/1 | 1/1/1/1 | 1/1/1/1 | 1/1/1/1 |
| | Pin probe 1 kV (banana sock- et) red / blue / yellow wasonreogb1 / wasonbuogb1 / wasonyeogb1 | 1/1/1 | 1/1/1 | 1/1/1 | 1/1/1 | 1/1/1 |
| | Test lead 15 m, blue (on a reel) WAPRZ015BUBBSZ | 1 | 1 | 1 | 1 | 1 |

Standard accessories

| | MPI-540-PV Solar | MPI-540-PV | MPI-540-PV Start | MPI-540 | MPI-540 Start |
|---|---------------------|--------------|---------------------|------------|------------------|
| | WMGBMPI540PVIRM1 | WMGBMPI540PV | WMGBMPI540PVNC | WMGBMPI540 | WMGBMPI540NC |
| Test lead 30 m, red (on a reel waprzosorebbsz |) 1 | 1 | 1 | 1 | 1 |
| Earth contact test probe (rod wasong30 |), 30 cm 2 | 2 | 2 | 2 | 2 |
| Voltage adapter with M4/ M6 thread (set of 4 pcs.) WAADAM4M64 | 1 | 1 | 1 | 1 | 1 |
| USB cable WAPRZUSB | 1 | 1 | 1 | 1 | 1 |
| 4 GB microSD card WAPOZMSD4 | 1 | 1 | 1 | 1 | 1 |
| Mains cable with IEC C7 plug WAPRZLAD230 | 1 | 1 | 1 | 1 | 1 |
| Z-7 power supply WAZASZ7 | 1 | 1 | 1 | 1 | 1 |
| Cable for battery charging fro cigarette lighter socket (12 V WAPRZLAD12SAM | om car) 1 | 1 | 1 | 1 | 1 |
| Li-Ion battery 11.1 V 3.4 Ah WAAKU15 | 1 | 1 | 1 | 1 | 1 |
| L-2 hanging straps (set) WAPOZSZEKPL | 1 | 1 | 1 | 1 | 1 |
| Carrying case M-13 WAFUTM13 | 1 | 1 | 1 | | |
| L-2 carrying case WAFUTL2 | 1 | 1 | 1 | 1 | 1 |
| Factory calibration certificate | e 1 | 1 | 1 | 1 | 1 |

Optional accessories



Solar radiation measurement set only for MPI-540-PV / MPI-540-PV Start WMGBIRM1MPI

F-1A flexible clamp

(Ø 360 mm)

WACEGF1A0KR



EVSE-01 adapter for testing vehicle charging stations WAADAEVSE01

F-2A flexible clamp

(Ø 235 mm)

WACEGF2AOKR

C-4A clamp

(Ø 52 mm)

1000 A AC

WACEGC4AOKR

C-7A clamp

(Ø 24 mm)

WACEGC7AOKR

100 A AC



AutoISO-1000C adapter

WAADAAISO10C

F-3A flexible clamp (Ø 120 mm) only for MPI-540 Start / MPI-540-PV Start



C-5A clamp (Ø 39 mm) 1000 A AC/DC

WACEGC5AOKR





WACEGN1BB



Hard carrying case for clamps WAWALL2

L-3 carrying case (for 80 cm test probes)

ter probe with WS-06 plug

only probe with miniDIN-4P plug WAADALP1

WAADAWS06

Calibration certificate with accreditation



C-3 clamp (Ø 52 mm) WACEGC30KR



C-6A clamp (Ø 20 mm) 10 A AC WACEGC6AOKR



Three-phase socket adapter 16 A / 32 A WAADAAGT16C WAADAAGT32C

Industrial socket

WAADAAGT16T WAADAAGT32T

Cramp with

WAZACIMA1

LP-10A light

WS-06 plug set WAADALP10AKPL

only probe with

WAADALP10A

WAADAWS06

miniDIN-4P plug

miniDIN-4P socket

(banana plugs)

WAPRZ005REBB

WAPRZ010REBB WAPRZ020REBB

meter probe with

banana socket

adapter 16 A / 32 A



Three-phase socket adapter 16 A / 32 A WAADAAGT16P

WAADAAGT32P

with UNI-SCHUKO angular plug

WAADAWS04

probe 80 cm

LP-10B light

miniDIN-4P plug WAADALP10B

miniDIN-4P socket WAADAWS06



WS-04 adapter

Earth contact test

WS-06 plug

Test lead for measurement 25 m / 50 m

WAPRZ050YEBBSZ



meter probe with

only WS-06 adapter with



only WS-06 adapter with





page 10 / 10



only probe with

earth resistance

set WAADALP10BKPL

WAPRZ025BUBBSZ



only WS-06 adapter with miniDIN-4P socket



sonel.com



WAFUTL3

LP-1 light me-

set WAADALP1KPL